



Please note that you may find it easier to paint the kit parts prior to assembly.

- 1 - Begin by removing the parts from the sprues as pictured.
- 2 - Glue the 4 decorative panels into position on the base.
- 3 - Glue the wall cap into place.
- 4 - Remove the pulley wheel and the six rope guides from the sprues.
- 5 - And glue the rope guides into place on the wheel.
- 6 - Glue the shaft to the pulley wheel assembly.
- 7 - Glue one of the shaft bearings to the ladder section.
- 8 - Slip the pulley wheel into place. If you want the wheel to rotate, do not glue the shaft to the bearing.
- 9 - Fit the second bearing to the pulley shaft and glue to the ladder part.

Assembly Instructions Continue on Page 2.





- 10 - Glue the 2 upper frames into place as pictured.
11 - The completed pulley assembly can now be glued in place.
12 - Fit the 2 roof support bars into place as in the picture. Set aside to dry.
13 - Carefully remove the roof base plate from the sprue.
14 - Glue this triangular roof bracket into place first.
15 - Followed by the second roof bracket - note that this one has a finial to the top.
16 - Gather together the 4 small triangular roof supports.
17 - And glue them into position thus.
18 - Now the 4 roof panels can be glued into position. You can run a small amount of glue where the corners meet on the 'hips' to make this assembly stronger. This is indicated in the picture by the red lines.
19 - Fit the roof assembly to the main well part. Glue is optional.
20 - Glue the 2 small circular parts to the decorative finial.
21 - Fix the 4 card roof tile sheets in place and the 4 bamboo poles to cover the joints. Your Chinese Well is now complete. Paint to your own taste.