



1 - Remove the front and back panels and the hinges from the sprues.  
 2 - Insert one hinge only to each door or window.  
 3 - Fit the doors - do not glue the door to the hinge - then fit the bottom hinge to each door.  
 4 - Repeat the process for the shutters.  
 5 - Fit the window sills to the front panel as shown.  
 6 - Sills fitted and glued in place.  
 7 - Fit the front and back panels and the two end walls.  
 8 - The wooden cladding panels can now be glued into place.  
 9 to 11 - Glue the roof panels to the v shaped end sections.  
 12 - Glue the ridge part in place.  
 13 - Run some glue to the under side of the roof assembly. This will strengthen the roof.  
 14 - Once dry, glue the roof tile sheets into place. Use pegs or clamps as shown. This will allow you to curve the roof sheet to fit the contour of the roof.  
 15 - When dry remove the pegs and fir the roof.  
 16 and 17 - The building is now complete. Note that you may find it easier to paint some or all of the parts prior to assembly.

**THE 55TH DAY  
IN BEIJING**

