

1**2****3****4****5****6****7****8****9****10****11****12****13****14****15**

Please note that most components in this assembly have been painted prior to assembly. You might find it more convenient to do this too.

1 - Door removed from sprue.

2 - Front wall, door and hinges.

3 - Glue into place the top hinge for the door.

4 - Slide the door into the top hinge. Do not glue the door to the hinges as you'll want it to open and close.

5 - Then glue the bottom hinge into place.

6 - Fit the front wall assembly to the base. Note that the small square holes in the base should line up with the unpainted areas of the wall

7 - The first side wall can be glued into place.

8 - And the second side wall.

9 - Then we can fit the rear wall of the building.

10 - And the upper part of the rear wall.

11 - Loosely fit the roof panel to the rear extension. Do not glue yet.

12 - Now fit the timber frame to the side wall.

13 - Followed by the 2 on the rear wall. The roof panel can be glued once the bottom frame is fitted.

14 - And the second side frame and the front.

15 - Fit the Grey card roof tile sheet as shown.

~ continued on page 2 ~

**THE 55TH DAY
IN BEIJING**





16 - Fix the two roof support brackets with holes in to the ridge part.
17 - Followed by the centre bracket.
18 - Fit the 3 roof boards to the roof assembly.
19 - And the other 3 to the second side.
20 - Fit the 2 'V' shaped parts to the roof ends.
21 - Run lines of glue as shown.
22 - Using pegs or clamps fit the greyboard roof tiles into place.
23 - Repeat for the second side. Allow the glue to fully dry before you remove the clamps.
24 - Fit the roof panels to the centre V part as shown to hide the construction tabs.
25 - Fit the completed roof assembly to the building. Paint to suit your own tastes. As previously stated, you may find it easier to paint some or indeed all of the parts before assembly.

THE 55TH DAY
IN BEIJING

