



Dutch Village House

Please note that you may find it easier to paint some parts prior to or during assembly.

1 - The kit contains the sprues as pictured. If your kit is missing items please contact us immediately.

2 - Fit the back wall and one gable to the floor panel.

3 - Fit the front wall and second gable as shown. Set this assembly aside to dry.

Note that it is important that the floor is fitted correctly to the bottom of the wall in order for the window inserts to line up correctly later.

4 - Remove the doors, hinges and front/rear window inserts from the sprues

5 - Fit the upper hinges as shown.

Dutch Village House

- 6 - Fit the doors into the upper hinges, note that no glue is required for this stage. Glue the lower hinge into place - as with the upper hinge, do not put glue onto any part of the door or the door will not open and close. Set the inserts aside to dry.
- 7 - Fix the three window/door inserts in place to the interior of the building.
- 8 - Remove the roof parts from the sprues as pictured.
- 9 - Fit the 4 roof panels to the trusses as shown.
- 10 - once dried the roof can be set in place on the building.
- 11 - The chimney assembly can be glued together next.
- 12 - When the chimney is dry file, sand or cut the protruding part as shown. This will allow the chimney to sit correctly against the roof.
- 13 - Fit the chimney to the roof - you can fit it anywhere on the roof. Glue the chimney cap into place.
- 14 - There are optional shutters supplied with the kit, these can be applied or not as desired.
- 15 - The kit is now complete.

