



THE 55TH DAY
IN BEIJING

- 1 - Select the 4 parts for the lower walls as shown.
- 2 - Glue the walls together.
- 3 - Fit the building base plate to the top of the walls.
- 4 - Select the components as shown - There are 2 sets of these for the front and back steps.
- 5 - The steps are numbered 1-4 fit them in place as shown - note the etching on the side walls are to the inside.
- 6 - The completed step.
- 7 - Fit the front and back steps into place.
- 8 - The outer layers of the steps can now be glued into place.
- 9 - Remove the front and back panels and the hinges from the sprues.
- 10 - Insert one hinge only to each door or window gap.
- 11 - Fit the doors and shutters - do not glue the door or shutter to the hinge - then fit the remaining hinge to each door or shutter.
- 12 - Glue the completed front and back panels in place on the building base.
- 13 - Fit the end walls.
- 14 - The 2 end walls can be fitted with the next part as shown - note the hollow cutout to this part and the etching to the outer face.
- 15 - The 2 final parts can be glued into position on the end walls.
- 16 - The timber cladding parts can be fitted to the front and rear of the building.
- 17 - Fit the window sills to the front panel as shown.
- 18 - Fit the centre roof truss to the ridge part.
- 19 - Followed by the 2 end trusses - note that these have a small hole in them - the centre truss does not.
- 20 - Begin fitting the roof panels into position.
- 21 - The fitting of the roof panels can now be completed.
- 22 - Test fitting of the roof panel.
- 23 - Glue the roof tile sheets into place. Use pegs or clamps as shown. This will allow you to curve the roof sheet to fit the contour of the roof.
- 24 - When dry remove the pegs and fit the roof. Your building is now complete.

Note that you may find it easier to paint some or all of the parts prior to assembly.

