



- 1- Remove the front panel, door and a set of the hinges from the sprues. There is a spare set of hinges in case of breakages.
- 2 - Insert the top hinge only to the door gap.
- 3 - Fit the door - do not glue the door to the hinge - then fit the bottom hinge to the door.
- 4 - Fit the front wall and one side wall to the base panel. Be careful to locate the base so the door will open freely.
- 5 - Glue the second side wall and the rear wall into place.
- 6 - Fix the front porch walls into place.
- 7 - Followed by the roof section.
- 8 - And the ridge part.
- 9 - Finally you can fit the roof panel to the front porch.
- 10 - Fit the centre roof truss to the ridge part.
- 11 - Followed by the 2 end trusses - note that these have a small hole in them - the centre truss does not.
- 12 - Fit this roof panel into position noting the location of the X etched on this part.
- 13 - Glue the remaining roof panels into place as shown.
- 14 - The end panels of the roof can be fitted into place next.
- 15 - Glue the smaller roof panel into place.
- 16 - Run lines of glue across the roof assembly as shown.
- 17 - Fix the larger roof tile sheet into place. Use pegs or clamps as shown. This will allow you to curve the roof sheet to fit the contour of the roof.
- 18 - Allow the glue to fully dry before removing the pegs. Fit the end caps to hide the construction tabs.
- 19 - Finally you can fit the roof. Your building is now complete.

Note that you may find it easier to paint some or all of the parts prior to assembly. We recommend that parts are carefully removed from the sprues with a sharp hobby knife. We have found that a good quality PVA glue works best with the MDF and Greyboard parts of these kits.

